Lakeside™ 15'x10'

Instructions apply to Part Number 9163-150

When You Are Ready To Set Up Your Tent

–Select a level campsite clear of rocks, branches and other hard or sharp objects.
–Do not set up your tent under trees.
–For best results in windy conditions, position the end of tent into the wind.
–See owners manual for more tips.

Main Poles
Part No. 9163-503

Main Pole
Part No. 9163-505

Rainfly Poles
Part No. 9163-504

Main Tent Poles (Black)

Main Tent Poles (Grey)

Rainfly
Part No. 9163-502

1 Layout & Positioning of Tent, Pole Assembly

–Layout and position tent with door facing desired direction. (illus. 1)
–Unzip doors.
–Stake down tent corners only, using the stake loops. Keep the floor taut. (Intermediate loops will be staked later.)
–Assemble frame poles by interlocking shock-corded poles. (three poles)
–Insert the grey pole straight through the center pole sleeves in the middle of tent. Then insert black poles straight through outside pole sleeves. (illus. 1)

illus. 1



illus. 2
Tent stake through stake loop



2 Connect Frame to Tent

–Start with the center Grey main pole. Insert the pin into the end of the grey main tent pole at tent's edge. (illus. 3 & 4)
–Go to opposite end of pole and gradually apply pressure to the pole forming an arch until you are able to insert the pin into the opposite pole end.
–Repeat for two black main poles.



illus. 4
Tent frame set-up



illus.3
Insert pin into pole end

3 Attach Tent to Frame Using Frame Clips

–Attach frame clips on the tent to frame poles. (illus. 5 & 6)
–Make any adjustments to the tent corner stakes, if needed.
–Stake out remainder of intermediate loops.
–Stake out door mat.



illus. 5
Frame clips

illus. 6 Assembled tent without rainfly.
Note the frame clips located on the tent.

4 Attach Rainfly

–Assemble rainfly poles by interlocking shock-corded poles.
–Insert rainfly poles into pole sleeves located at the ends of the underside of rainfly. (illus. 7)
–Drape rainfly over tent frame, pole side down. Rainfly poles should cover doors at ends of tent.
–Connect the four elastic loops with “S” hooks, (found at the rainfly corners) to the four stake loops located at the corners of the tent.
–Insert the tips of the rainfly poles into the grommets on the front and rear of tent. (See above illus. 6)
–Secure rainfly with attachments located on underside of fly. (illus. 8)
–Attach and stake out guylines.



illus. 8
Completed tent with rainfly.

“S” Hooks attach to rings at the corners

Things You Should Know

- Under certain conditions (cold weather, high humidity, etc.) condensation will form on the inside surfaces of your tent. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside your tent. It is NOT LEAKAGE through the tent fabric. It can be minimized by removing wet clothing from your tent and by providing good ventilation through the tent.
- Never store tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your tent. Use a separate storage bag.
- STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE TENT FABRIC OR TENT STAKE LOOP TO REMOVE STAKE.
- TENT POLES SHOULD NOT BE LEFT TELESCOPED TOGETHER DURING STORAGE.
- Seam sealer has not been provided with your tent. We recommend seam sealing your tent prior to camping. Seam sealer may be purchased through your local retailer or at your local sporting goods store.
- Do not leave your tent set-up for weeks at a time, be aware that exposure to the ultraviolet rays of the sun can seriously damage material and/or cause it to become discolored.
- See owners manual for more tips.

WARNING: **KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.** This tent meets the flammability requirements of CPAI-84. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

THE COLEMAN CO., INC.
3600 N. Hydraulic • Wichita, Kansas 67219
1-800-835-3278 • www.coleman.com

PRINTED IN CHINA Rev. 10/03

MADE IN CHINA